

Unidad de expansión	Modelos compatibles
RX1217(RP)	RS3617xs+, RS3617RPxs, RS3617xs, RS3614xs+, RS3614(RP)xs, RS2416(RP)+, RS2414(RP)+, RS3413xs+, RS3412(RP)xs, RS3411(RP)xs, RS2212(RP)+, RS2211(RP)+
RX1216sas	RS18016xs+
RXD1215sas	RC18015xs+
RX1211(RP)	RS3413xs+, RS3412(RP)xs, RS3411(RP)xs, RS2212(RP)+, RS2211(RP)+
DX1215	DS3617xs, DS3615xs, DS2015xs, DS3612xs, DS3611xs, DS2415+, DS2413+, DS2411+
DX513	DS1815+, DS1813+, DS1812+, DS1515+, DS1515, DS1513+, DS1512+, DS1511+, DS1010+, DS916+, DS716+, DS716+II, DS715, DS713+, DS712+, DS710+
RX415	RS815(RP)+, RS814(RP)+, RS816, RS815, RS814, RS812(RP)+, RS812